

LCD DIGITAL POCKET SIZE THERMOMETER

- FUNCTION:**
- ON/OFF
 - HIGH ALARM
 - ONE HOUR AUTO SHUT OFF
 - HI/T
 - LOW ALARM
 - ALARM ON/OFF
 - WATERPROOF
 - MAX/MIN MEMORY RECALLING

FEATURE:

- 1.5" MM STAINLESS STEEL SENSOR PROBE
- PIERCING PROBE [] SURFACE PROBE [] AIRFLOW PROBE [] ROBUST SENSOR PROBE
- PROTECTIVE PLASTIC SLEEVE WITH CLIP FOR STAINLESS STEEL
- PROTECTIVE CAP FOR STAINLESS STEEL
- 1 SECOND NORMAL TEMPERATURE SENSING TIME
- LOW BATTERY INDICATOR

SPECIFICATION:

- MEASUREMENT RANGE: -50°C ~ +150°C OR -58°F ~ +302°F
 -50°C ~ +300°C OR -58°F ~ +572°F
- RESOLUTION: 0.1° FOR -19.9° ~ +199.9°, OTHERWISE 1°
- ACCURACY: ±1°C IN THE RANGE OF -30°C ~ +150°C
 ±1.8°F IN THE RANGE OF -22°F ~ +302°F
 ±1°C IN THE RANGE OF +151°C ~ +250°C, OTHERWISE MORE THAN ±2°C
 ±1.8°F IN THE RANGE OF +303.8°F ~ +482°F, OTHERWISE MORE THAN ±4°F
- AMBIENT TEMPERATURE FOR PLASTIC CASING: -10°C ~ +50°C OR +14°F ~ +122°F
- BATTERY: 1 X 1.5V "A76" SIZE (LR44, G13) OR EQUIVALENT
 1 X 1.5V "393" SIZE OR EQUIVALENT
 1 X 1.5V "G10" SIZE OR EQUIVALENT

INSTALLATION:

- UNPACK THE THERMOMETER WITH CARE.
- OPEN THE BATTERY DOOR, INSTALL THE BATTERY INTO THE BATTERY COMPARTMENT, THEN CLOSE THE BATTERY DOOR.
- SLIDING PLASTIC SLEEVE, THE THERMOMETER IS NOW READY FOR USE.
- REPLACE NEW BATTERY WHEN THE LOW BATTERY INDICATOR APPEARS ON THE SCREEN.

OPERATION:

- SLIDE/PRESS THE "ON/OFF" SWITCH/BUTTON, ALL FUNCTIONS WILL SHOW ON THE DISPLAY. THE THERMOMETER IS READY FOR USE.
- "C/F" --- TO SELECT DESIRED TEMPERATURE UNIT.
- "HI/T" --- PRESS ONCE, "HOLD" FLASH TO RETAIN READING FOR RECORDING.
- "MAX / MIN" --- PRESS ONCE TO RECALL MINIMUM TEMPERATURE TESTED. PRESS AGAIN FOR MAXIMUM TEMPERATURE TESTED. TESTING MODE WILL RESTORE AFTER 3 SECONDS

TEMPERATURE ALARM SETTING:

- PRESS THE "LOW AL" OR "HI AL" BUTTON FOR SETTING ALARM AT DESIRED LOW AND HIGH TEMPERATURE. PRESS THE "LOW AL" BUTTON, THE "LOW" SIGN APPEARS. PRESS THE "HI AL" BUTTON, THE "HIGH" SIGN WILL BE SHOWN. THE DISPLAY WILL SHOW -50°C OR -58°F AND START TO INCREASE UP TO +150°C OR +302°F / +299°F OR +572°F.
- RELEASE THE "LOW AL" OR "HI AL" ALARM SET BUTTON WHEN THE DESIRED TEMPERATURE IS REACHED. THE THERMOMETER WILL RETURN TO NORMAL MODE AFTER 3 SECONDS.
- THE ALARM WILL SOUND IN 4 BEEPINGS WHEN THE MEASURED TEMPERATURE IS GREATER THAN THE MAXIMUM OR LESS THAN THE MINIMUM SET VALUE.

PRECAUTIONS:

- TO OBTAIN THE BEST RESULTS, THE PROBE TIP SHOULD BE IMMERSUED AT LEAST 10MM. INTO THE TESTED SUBSTANCE.
- REMOVE THE BATTERY FROM THE BATTERY COMPARTMENT IF THE THERMOMETER WILL NOT BE USED FOR LONG DURATION OF TIME OR DURING STORAGE.
- THE THERMOMETER CANNOT BE USED OR PUT INSIDE ANY OVEN OR MICROWAVE.
- PLACE THE PLASTIC O-RING AT THE APPROPRIATE POSITION AFTER OPENING THE BATTERY DOOR TO ENSURE THE WATERPROOF FUNCTION. (FOR PRODUCT WITH WATERPROOF FUNCTION ONLY).

64 ST-PK 0E-01

LCD DIGITAL POCKET SIZE THERMOMETER

- FUNCTION:**
- ON/OFF
 - HIGH ALARM
 - ONE HOUR AUTO SHUT OFF
 - HI/T
 - LOW ALARM
 - ALARM ON/OFF
 - WATERPROOF
 - MAX/MIN MEMORY RECALLING

FEATURE:

- 1.5" MM STAINLESS STEEL SENSOR PROBE
- PIERCING PROBE [] SURFACE PROBE [] AIRFLOW PROBE [] ROBUST SENSOR PROBE
- PROTECTIVE PLASTIC SLEEVE WITH CLIP FOR STAINLESS STEEL
- PROTECTIVE CAP FOR STAINLESS STEEL
- 1 SECOND NORMAL TEMPERATURE SENSING TIME
- LOW BATTERY INDICATOR

SPECIFICATION:

- MEASUREMENT RANGE: -50°C ~ +150°C OR -58°F ~ +302°F
 -50°C ~ +300°C OR -58°F ~ +572°F
- RESOLUTION: 0.1° FOR -19.9° ~ +199.9°, OTHERWISE 1°
- ACCURACY: ±1°C IN THE RANGE OF -30°C ~ +150°C
 ±1.8°F IN THE RANGE OF -22°F ~ +302°F
 ±1°C IN THE RANGE OF +151°C ~ +250°C, OTHERWISE MORE THAN ±2°C
 ±1.8°F IN THE RANGE OF +303.8°F ~ +482°F, OTHERWISE MORE THAN ±4°F
- AMBIENT TEMPERATURE FOR PLASTIC CASING: -10°C ~ +50°C OR +14°F ~ +122°F
- BATTERY: 1 X 1.5V "A76" SIZE (LR44, G13) OR EQUIVALENT
 1 X 1.5V "393" SIZE OR EQUIVALENT
 1 X 1.5V "G10" SIZE OR EQUIVALENT

INSTALLATION:

- UNPACK THE THERMOMETER WITH CARE.
- OPEN THE BATTERY DOOR, INSTALL THE BATTERY INTO THE BATTERY COMPARTMENT, THEN CLOSE THE BATTERY DOOR.
- SLIDING PLASTIC SLEEVE, THE THERMOMETER IS NOW READY FOR USE.
- REPLACE NEW BATTERY WHEN THE LOW BATTERY INDICATOR APPEARS ON THE SCREEN.

OPERATION:

- SLIDE/PRESS THE "ON/OFF" SWITCH/BUTTON, ALL FUNCTIONS WILL SHOW ON THE DISPLAY. THE THERMOMETER IS READY FOR USE.
- "C/F" --- TO SELECT DESIRED TEMPERATURE UNIT.
- "HI/T" --- PRESS ONCE, "HOLD" FLASH TO RETAIN READING FOR RECORDING.
- "MAX / MIN" --- PRESS ONCE TO RECALL MINIMUM TEMPERATURE TESTED. PRESS AGAIN FOR MAXIMUM TEMPERATURE TESTED. TESTING MODE WILL RESTORE AFTER 3 SECONDS

TEMPERATURE ALARM SETTING:

- PRESS THE "LOW AL" OR "HI AL" BUTTON FOR SETTING ALARM AT DESIRED LOW AND HIGH TEMPERATURE. PRESS THE "LOW AL" BUTTON, THE "LOW" SIGN APPEARS. PRESS THE "HI AL" BUTTON, THE "HIGH" SIGN WILL BE SHOWN. THE DISPLAY WILL SHOW -50°C OR -58°F AND START TO INCREASE UP TO +150°C OR +302°F / +299°F OR +572°F.
- RELEASE THE "LOW AL" OR "HI AL" ALARM SET BUTTON WHEN THE DESIRED TEMPERATURE IS REACHED. THE THERMOMETER WILL RETURN TO NORMAL MODE AFTER 3 SECONDS.
- THE ALARM WILL SOUND IN 4 BEEPINGS WHEN THE MEASURED TEMPERATURE IS GREATER THAN THE MAXIMUM OR LESS THAN THE MINIMUM SET VALUE.

PRECAUTIONS:

- TO OBTAIN THE BEST RESULTS, THE PROBE TIP SHOULD BE IMMERSUED AT LEAST 10MM. INTO THE TESTED SUBSTANCE.
- REMOVE THE BATTERY FROM THE BATTERY COMPARTMENT IF THE THERMOMETER WILL NOT BE USED FOR LONG DURATION OF TIME OR DURING STORAGE.
- THE THERMOMETER CANNOT BE USED OR PUT INSIDE ANY OVEN OR MICROWAVE.
- PLACE THE PLASTIC O-RING AT THE APPROPRIATE POSITION AFTER OPENING THE BATTERY DOOR TO ENSURE THE WATERPROOF FUNCTION. (FOR PRODUCT WITH WATERPROOF FUNCTION ONLY).

64 ST-PK 0E-01