

POOL CHECK™

eXact™ Reagent

PART NUMBER 481652

The eXact™ Reagent CY (481652) offers safe and convenient digital Cyanuric Acid testing for your pool. For use with the eXact™ 3 and 9 meters, eXact™ Reagent CY is a liquid reagent that eliminates the need for “difficult to read” Cyanuric Acid tests with color charts.



**Pool Check™
eXact™ Reagent
For Cyanuric Acid**

**(For Use With
eXact™ 3 & 9 Meters)**

Available For Private Label.

Test Procedure (eXact™ 3 meter example):

Step 1: Rinse supplied plastic vial 1 or 2 times and fill to line with pool water sample. **DO NOT OVERFILL!** Dry outside of vial with a soft paper or cloth towel.

Step 2: Lift the chamber lid and insert plastic vial. Close lid.

Step 3: Press the “Menu” key to switch the meter on. Press the “menu” key twice to display the “CY” symbol.

Step 4: Press the “B” key to blank the meter to 0.

Step 5: Open the chamber lid and, with the vial still in the meter, add 5 drops of eXact™ Reagent CY. **For best results, shake eXact™ Reagent CY bottle well before use.** Cap the plastic vial and close the chamber lid. Rotate the meter over and back for 20 seconds to mix. Hold the meter upright and wait 10 seconds (see Note below). Press the “R” key and read the display. Multiply by 10 to get the Cyanuric Acid concentration in ppm (parts per million). Example: a displayed value of 4.5 x 10 gives a result of 45 ppm.

Detection Range:

Cyanuric Acid: 0 - 200 mg/L

Packaging:

Bottle of 100 tests

DIGITAL POOL & SPA TESTING

INDUSTRIAL TEST SYSTEMS, Inc.

1875 Langston Street, Rock Hill, SC 29730

Phone: 1-800-861-9712 Fax: 1-803-329-9743

For International: 001-803-329-9712 ext 220 (Pablo)

Web: www.poolcheckonline.com Email: its@cetlink.net



Member of

